



JORDAN VALVE

3170 Wasson Road • Cincinnati, OH 45209 USA
 Phone 513-533-5600 • Fax 513-871-0105
 info@richardsind.com • www.jordanvalve.com

I & M Mark 608IS


Installation & Maintenance Instructions for Mark 608IS Gas Pressure Regulators

Warning: Jordan Valve Pressure Regulators must only be used, installed and repaired in accordance with these Installation & Maintenance Instructions. Observe all applicable public and company codes and regulations. In the event of leakage or other malfunction, call a qualified service person; continued operation may cause system failure or a general hazard. Before servicing any valve, disconnect, shut off, or bypass all pressurized fluid. Before disassembling a valve, be sure to release all spring tension.

Please read these instructions carefully!

Your Jordan Valve product will provide you with long, trouble-free service if it is correctly installed and maintained. Spending a few minutes now reading these instructions can save hours of trouble and downtime later. When making repairs, use only genuine Jordan Valve parts, available for immediate shipment from the factory.

Ideal Installation



- To protect the regulator from grit, scale, thread chips and other foreign matter, ALL pipelines and piping components should be blown out and thoroughly cleaned before the installation process begins.
- Shutoff valves, pressure gauges and by-pass piping should be installed as indicated in the Installation Schematic to provide easier adjustment, operation, and testing.
- In preparing threaded pipe connections, care should be exercised to prevent pipe sealing compound from getting into the pipe lines. Pipe sealing compound should be used sparingly, leaving the two end threads clean. Jordan recommends Teflon tape.
- A line strainer should be installed on the inlet side of the regulator to protect pipe from grit, scale and other foreign matter. A 0.033 perforated screen is usually suitable for this purpose. Line strainers are

- available from Jordan Valve.
- The flow arrow on the regulator body must be pointed in the direction of flow. The regulator may be installed in any position. The actuator may be rotated to any position relative to the body. (See sizing.) Loosen the union nut and position the actuator. Pull the union nut up hand-tight, then tighten 1/4 turn. (The union nut is 8-sided and may be used as a guide.)
- Provisions are provided to vent the case from the top or bottom by a 1/4" pipe tap opening. One opening is plugged, the other has a screened (bug) vent. Reverse these if it is desired open vents should point downward; a street elbow can be used if needed. Some installations will require that this vent be piped to some location external to the regulator. When remote piping is used, 1/4" size is adequate. NEVER BLOCK OFF THE VENT LINE. Follow local regulations.
- Install a relief valve downstream from the regulator to protect downstream components from over-pressurization. Generally, the setting of the relief valve should be at least 20% greater than the regulator set point. It must have adequate flow capacity to protect the downstream components should the regulator fail to shut off.
- Operate the regulator within its rated pressure and temperature. The standard Mark 608IS is rated at 150 psig max (inlet or outlet section) at -20 to +200°F. Regulator ratings and materials of construction are listed on the valve name plate.

Sizing

Refer to the sizing charts for the flow capacity of the regulator under various conditions in the sales literature.

Regulators of this type are sensitive to inlet pressure because the flow tends to open the valve. For lower set-points, the orifice size can be limited by the operating inlet pressure. Because of the weight of the diaphragm assembly and friction in the moving parts, there is a difference in the lowest setpoint attainable when the actuator housing is upright, or inverted. (Upright refers to the spring housing cap pointing vertically up.) Lower set

points can be achieved with the housing inverted.

With this information, refer to the flow capacity chart in the Mark 608 Bulletin.

Start-Up

1. Fully open the outlet shut-off valve.
2. Slowly open the inlet shut-off valve.
3. Slowly open and close the outlet shut-off valve several times. This fully strokes the valve to insure satisfactory operation.
4. With the outlet shut-off valve open and preferably at a low flow, slowly turn the adjusting screw until the desired pressure is shown on the outlet pressure gauge.
5. To change the controlled pressure, turn the adjusting screw clockwise to increase pressure, and counterclockwise to decrease pressure.
6. Make sure to allow time for pressure to stabilize before making any changes.

Trouble Shooting

If You Experience Erratic Control:

- Oversizing causes cycling and hunting and reduces the rangeability of the valve. Make certain that your sizing is correct.
- Attempting to exceed flow capacity. Make certain that your sizing is correct.
- Blocked vent line or vent passage in spring housing. Clean.
- Inlet pressure varying greatly. Stabilize or use second regulator to control inlet pressure closer.

If You Cannot Set Outlet Pressure:

- Orifice too large for inlet pressure. Refer to Sizing.
- Improper spring.
- Incorrect actuator mounting, change position.

If the Valve Will Not Operate:

- Diaphragm ruptured. Replace.
- Adjusting spring broken. Replace.

Maintenance

WARNING: Be sure that there is no pressure in the valve before loosening any fittings or joints. The following steps are recommended:

1. Close the inlet shut-off valve, and by-pass valve.
2. Back off adjusting screw to allow inlet pressure to open seats.
3. Allow pressure to bleed off through downstream piping.
4. When the inlet pressure gauge indicates no pressure in the line, close the outlet shut-off valve.

Refer to the drawings for the proper orientation of the parts and for proper nomenclature.

A. DIAPHRAGM REPLACEMENT

1. Remove all pressure from the line as outlined under WARNING.
2. Remove the compression of the adjusting spring (22) by rotating the adjusting screw (19) counterclockwise.
3. Loosen the spring housing bolts (16) and remove spring housing.
4. Remove diaphragm subassembly by sliding it away from the valve body to disengage the lever arm (7).
5. Hold the lower diaphragm plate (5) and remove the screw (6), separating the parts.
6. Clean the surfaces on the upper (4) and lower diaphragm plates (5) that the diaphragm (3) seats against. Clean and degrease the threads on the lower diaphragm plate and the screw. (Degrease with Loctite primer T.)
7. Assemble the upper and lower diaphragm plates to the new diaphragm with the screw. (Apply a few drops of Loctite #290 to the screw threads to lock the parts together.) The hole through the lower diaphragm plate must align with any pair of opposite holes in the diaphragm so that it will properly engage the lever when reassembled into the valve.
8. Clean the flange surface on the diaphragm housing and reinstall the diaphragm subassembly onto the lever arm.
9. Clean the flange surface on the spring housing.
10. Set the spring housing on top of the diaphragm housing. Using a 6" long screwdriver, or similar tool, reach through the spring housing and push the diaphragm down to align the diaphragm holes with the housings' holes if needed.
11. Drop the bolts into place and attach the lockwashers and nuts, finger-right.
12. Continue to push the diaphragm down and snug up the bolts.
13. Evenly torque the bolts as described in the drawing, Figure 3.
14. Install the spring and adjusting screw. (Adjusting spring per start-up instructions and replace cap.)

B. SEAT INSERT, PLUG, OR ASPIRATOR REPLACEMENT

1. Remove all pressure from the line as outlined under WARNING.
2. Loosen the union nut (24) and separate the actuator from the body.
3. Inspect the plug (11) and seat insert (26) to determine if replacement is required. Replace if there are signs of wear or uneven seating on either part.
4. To replace the seat, simply unscrew it from the body using a 7/8" thinwall socket wrench. Install the new seat o-ring. An anti-seize compound

- applied to the threads will aid in future removal.
5. To replace the plug, or aspirator (12), disassemble the actuator as described in steps A2, A 3, A4.
 6. Remove the two screws (9) fastening the lever arm bracket (8) to the diaphragm housing and lift out the lever arm bracket with the lever.
 7. Inspect aspirating hole in aspirator to be sure it is clean. Remove and replace aspirator if stem guide bore is worn. Remove and replace plug.
 8. Remove the screws from the lever arm bracket and clean the threads. Degrease with Loctite Primer T. Also clean and degrease the tapped holes in the diaphragm housing.
 9. Reassemble the screws.
 10. Apply a drop of Loctite #290 to each screw and reinstall the lever arm bracket. Align the slot in the plug's stem with the lever arm and tighten the pivot bracket's mounting screws. Check for free movement. Be certain that there is a gasket (29) between the aspirator flange and the diaphragm housing, and a gasket (30) in the body cavity where the aspirator fits.
 11. Re-attach body and actuator with the union nut (being careful to align the aspirator tube to the slot in the body). Pull up hand-tight, then tighten further 1/4 turn. (The union nut is 8-sided and may be used as a guide).
 12. If lever arm was replaced, apply 25-150 psi pressure through outlet. This will set linkage and prevent overpressure (in operation) from bending the linkage and causing set point changes. Seat leakage may be checked by observing any leakage from inlet.

C. SPRING REPLACEMENT

1. To replace a spring, remove the cap (21) and the adjusting screw (19). Then remove the spring.

CAUTION: If a different range spring is being installed, be sure the proper adjusting screw is used (the 3.5 psi range uses a different adjusting screw.) Failure to observe this caution could result in valve damage or failure to shut off. It is recommended that a new tag be issued for this valve with correct spring range.

2. Reinstall spring and adjusting screw. Adjust spring per startup instructions. Replace cap.

Ordering Spare Parts


Use only genuine Jordan Valve parts to keep your valve in good working order. So that we can supply the parts, which were designed for your valve, we must know exactly which product you are using. The only guarantee to getting the correct replacement parts is to provide your Jordan Representative with the valve serial number. This

number is located on the valve identification tag. If the serial number is not available, the parts needed for your valve might be determined using the following information: Model Number, Valve Body Size, Seat Material and Cv Rating, Spring Range and Set Point, Trim Material, Part Name - Number and Quantity.

NOTE: Any parts ordered without a valve serial number that are found to be incorrect are subject to up to a minimum 25% restock charge when returned.


Torque Procedure

1. Install all bolts hand-tight.
2. Torque the bolts in order of the bolt pattern to approximately 75 in-lbs.
3. Re-torque each bolt to 300 in-lbs, using the same bolt pattern as shown.



8 bolts
(or multiples)

Illustration and Parts List



Item	Description	Qty.	Item	Description	Qty.
1	Lower Diaphragm Case	1	16	Bolt	8
2	Spring Housing	1	17	Lockwasher	8
3	Diaphragm	1	18	Nut	8
4	Upper Diaphragm Plate	1	19	Adjusting Screw S/A	1
5	Lower Diaphragm Plate	1	21	Cap	1
6	RHMS	1	22	Range Spring	1
7	Lever Arm	1	23	Stop Pin	1
8	Lever Arm Bracket	1	24	Union Nut	1
9	Screw (Lever Arm)	2	25	Retaining Ring	1
10	Dowel Pin	1	26	Seat Insert	1
11	Plug	1	27	Body	1
12	Aspirator Tube Assembly	1	28	Name Plate	1
14	Vent Screen	1	29	Gasket (Aspirator Tube Upper)	1
15	Pipe Plug	1	30	Gasket (Aspirator Tube Lower)	1
			31	O-Ring	1